

Operation Steps

1. Plug the device into the socket
2. To start the disinfection, come closer to device, put your hands in the disinfection cell illuminated by the green light that lights up when the device detects you.
3. Take your hands off after 15 seconds when the light inside the cell is yellow and the warning sounds.
4. Continuous flashing red light in the disinfection cell means that the disinfectant liquid is finished.
5. In case the disinfectant liquid is drained, pull the cover on the lower side of the device to yourself.
6. Open the cover of the disinfectant fluid reservoir, pour the fluid into the reservoir and close the cover again.
7. Make sure that the tube that provides the steam outlet is in place.

Package Included

- I. Disinfection Stand
- II. Power Cable

Technical Specifications

Product Code	: T-BHR-01
Working Voltage	: 220VAC 50Hz
Power Consumption	: 48W
Maximum Steam Output	: 600-1000 ml/s
Sterilization Time	: 15sec
Sensor Distance	: 50cm
Dimensions	: 515mm*350mm*1580mm
Tank Capacity	: 15L
Weight	: 23kg

These values are determined according to the reference liquid. It may vary depending on the disinfectant liquid used.

Basic Characteristics

- TTAF Hand Disinfection Stand With Steam Effect provides hand disinfection without any contact to common areas where bacteria and viruses can spread rapidly.
- Disinfectant liquid is converted to cold steam with a special technology and it is provided to penetrate the skin better
- The disinfectant reaches every point of the hands in 15 seconds as intense cold steam.



HAND SANITIZING STAND WITH COLD STEAM EFFECT USER MANUAL



Kavaklı Mh. İstanbul Cd. No:21
Beylikdüzü -İstanbul /TÜRKİYE

Tel : +90 212 855 82 20 (Pbx)

Fax : +90 212 855 82 21

www.ttafmedikal.com

© f in /ttafelectronic